

Fitting Tips



By using packers you can get the perfect fit every time.

1) Always put a **4mm packer** under the hinge side leg. If the lock side needs lifting or dropping to square up the head you now have some room for that adjustment. Also seal with silicone between the threshold and cill to stop water ingress.



2) First fixing position should be two fingers below the top hinge. **Drill a pilot hole before fixing to brickwork** to avoid cracking the frame.

3) **Remove the rubber from your level** and get it right into the top when squaring up, you may find the frame is bending inwards in the top corner. This bending in of the frame causes issues with the way the sash hangs square.





4) The slight bending in of the top frame pushes the sash towards the lock side creating uneven air gaps, resist the temptation to adjust the hinge. Instead simply **insert a packer behind where your top fixing** will go. This will bring the sash back square in the frame and equal up the air gaps again.

